


Connecting to Wi-Fi at Home

Please note that you may need a password to connect to your home Wi-Fi connection if it set to private. This may have been provided to you by your Internet Service Provider or the password that was assigned to your wireless router.

IPAD AIR

- Tap the **Settings** icon on the Home screen.
- Tap **Wi-Fi** from the left-side of the Settings screen.



- A list of Wi-Fi connection will display on the left-side of the Wi-Fi screen.
- Choose a **Wi-Fi** connection.


Note: If a list does not appear you will have to **scan** for connections. To start scanning for available wireless connections, slide the Wi-Fi slider to "**on**". In a few seconds, you'll see a list of all the connections near you, whether they're public or private. If you don't see the list, there may not be any within range).

- If your connection is **Public** you **do not need a password:**
 - ✓ **Tap** the *network name* to connect.
- If there is a **lock** symbol:
 - ✓ **Tap** the connection.
 - ✓ Enter the **password**.
 - ✓ Tap **Join**.

- **Note:** Your tablet will be connected automatically the next time it is within range of this network.

ALCATEL ONETOUCH POP 8

- Touch the **Settings** icon on the Home screen.
- Under **Wireless & Network**, touch **Wi-Fi**.
- Slide the On/Off switch to **On**.
- Touch a **Wi-Fi** connection to connect.



Note: If the network you selected is secured, you are required to enter a password.

- Touch **Connect**.

Note: Your tablet will be connected automatically the next time it is within range of this network.